



Technical Bulletin 277
Mi-Glow[®] 800LS-RTU

Mi-Glow[®] 800LS-RTU is a Ready-to-Use oil bath packaged in a hand-held spray bottle. The bath contains Mi-Glow[®] 800 fluorescent yellow-green particles and CircleSol M[™], a refined petroleum distillate. It is designed for revealing very fine discontinuities, such as those found in finished products for the aerospace industry and other critical applications, using black light.

Properties

Particle Color: Fluorescent Yellow-Green

Concentration: 1.25 grams of Mi-Glow[®] 800 per liter of fluid.

Particle Size: Not less than 98% passage through US Standard No. 325 (45 μ m) sieve as defined in AMS 3044. The typical range of particle sizes is from 1 to 12 μ m, with an average particle size of 5 μ m.

Sensitivity: Mi-Glow[®] 800LS RTU shows a minimum of 8 lines on an AISI 01 Ketos tool steel ring (as defined in SAE AS5282), set on a 1-inch diameter copper bar, magnetized with 2500 A of direct current.

Particle Certification: Particles, carrier and mixture meet or exceed all relevant industry specifications, including but not limited to MIL-STD-1949, MIL-STD-271(SH), ASTM E 709, ASTM B & PV Code - Section V and NAVSEA 250-1500-1. AMS 3044, AMS 3045, AMS 3161, AMS 2641 and DOD-F-87935 are covered under MIL-STD-1949. Certification is included with each shipment.

Temperature Limits: 32-120°F (0-49°C)

Shelf Life: Five (5) years, when sealed bottles are not subjected to excessive heat or cold. A Certificate of Shelf Life is available upon request.

Directions for Use

Preparation: Thoroughly shake the bottle, insert the spray nozzle and apply to the parts for inspection.

Concentration Test: If it becomes necessary to verify the concentration in the bottle, thoroughly shake the bottle and the method of test should be as follows:

1. Fill a 100 ml graduated centrifuge tube as specified in Guide E709, or equivalent, to the 100 ml mark with suspension directly from the bottle. Demagnetize the suspension, if considered necessary, and let it stand undisturbed for a minimum of 30 minutes or until completely settled.
2. Read the volume of the precipitate in the graduate. The recommended volume is between 0.15 to 0.3 ml.

DISCLAIMER: OUR TECHNICAL ADVICE, INFORMATION AND STATEMENTS GIVEN VERBALLY, IN WRITING OR IN THE FORM OF TEST RESULTS, ARE OFFERED FOR YOUR GUIDANCE WITHOUT WARRANTY. NO WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE IS MADE. IT IS THE USER'S RESPONSIBILITY TO TEST THE SUITABILITY OF EACH PRODUCT FOR HIS INTENDED PROCESS AND APPLICATIONS. OUR GUARANTEE IS LIMITED TO THE CONSISTENT QUALITY OF OUR PRODUCTS.
